



ubbink

Installation regulations

Ubiflux Vigor W325

English



Installation regulations

Heat recovery appliance

Ubiflux Vigor W325 (Plus)



Store near the appliance

This appliance may be used by children as of 8 years of age, persons with reduced physical or mental capacities, and persons with limited knowledge and experience if they are supervised or have received instructions on how to use the appliance safely and are aware of the possible dangers.

Children younger than 3 years of age must be kept away from the appliance, unless they are under constant supervision.

Children between the ages of 3 and 8 may only switch the appliance on or off, but only if supervised or if they have received clear instructions on the safe use of the appliance and understand the possible dangers, on the condition that the appliance has been placed and installed in the normal position for use. Children between the ages of 3 and 8 may not insert the plug into the socket, nor clean or make changes to the settings of the appliance, nor carry out any maintenance on the appliance that would normally be carried out by the user. Children may not play with the appliance.

If you need a new power cable, always order the replacement from Ubbink NV To prevent dangerous situations, a damaged mains connection must only be replaced by a qualified expert!

Country: GB

Contents

| | | | |
|--|----|--|----|
| 1 Delivery. | 5 | 11.2 Connecting Air Control. | 40 |
| 1.1 Delivery size. | 5 | 11.3 Connecting humidity sensor. | 41 |
| 2 General. | 6 | 11.4 Connecting CO ₂ sensor(s). | 42 |
| 3 Version. | 7 | 11.5 Demand-driven ventilation 2.0. | 43 |
| 3.1 Technical information. | 7 | 11.6 Connecting postheater. | 44 |
| 3.2 Connections and dimensions. | 8 | 11.7 Connecting preheater. | 45 |
| 3.3 Exploded view of appliance. | 10 | 12 Service. | 46 |
| 4 Operation. | 11 | 12.1 Exploded view. | 46 |
| 4.1 Description. | 11 | 12.2 Service articles. | 47 |
| 4.2 Bypass. | 11 | 13 Setting values. | 49 |
| 4.3 Frost protection. | 12 | 13.1 Setting values standard appliance. | 49 |
| 4.4 Plus version. | 12 | 13.2 Setting values appliance with Plus pcb. | 52 |
| 5 Installation. | 13 | 14 Conformity declaration. | 54 |
| 5.1 Installation general. | 13 | 15 ERP values. | 55 |
| 5.2 Placing the appliance. | 13 | 16 Recycling. | 57 |
| 5.3 Connecting the condensate discharge. | 14 | | |
| 5.4 Connecting air ducts. | 15 | | |
| 5.5 Electrical connections. | 16 | | |
| 5.5.1 Connecting the power plug. | 16 | | |
| 5.5.2 Connecting the multiple switch. | 16 | | |
| 5.5.3 Connecting the eBus connector. | 17 | | |
| 5.5.4 24 volt connection. | 17 | | |
| 5.5.5 Connecting humidity sensor. | 17 | | |
| 5.5.6 Bus Connection. | 17 | | |
| 5.5.7 Connecting "signal output" connector. | 17 | | |
| 5.5.8 ModBus Connection. | 17 | | |
| 5.5.9 Coupling appliances using Bus. | 18 | | |
| 6 Display. | 19 | | |
| 6.1 General explanation of control panel. | 19 | | |
| 6.2 Display layout. | 20 | | |
| 6.3 Display information. | 23 | | |
| 7 Starting appliance. | 24 | | |
| 7.1 Switching appliance on and off. | 24 | | |
| 7.2 Setting the air flow. | 24 | | |
| 7.3 Other settings for installer. | 25 | | |
| 7.4 Factory settings. | 25 | | |
| 8 Fault. | 26 | | |
| 8.1 Fault analysis. | 26 | | |
| 8.2 Display Codes. | 26 | | |
| 9 Maintenance. | 29 | | |
| 9.1 Cleaning filter. | 29 | | |
| 9.2 Maintenance. | 30 | | |
| 10 Electrical diagram. | 34 | | |
| 11 Electrical connections accessories. | 36 | | |
| 11.1 Connecting position switch. | 36 | | |
| 11.1.1 Connecting position switch with filter indication. | 36 | | |
| 11.1.2 Connecting wireless remote control (without filter indication). | 37 | | |
| 11.1.3 Connecting extra multiple switch with filter indication. | 38 | | |
| 11.1.4 Connecting extra multiple switch with filter indication. | 39 | | |


1 Delivery

1.1 Delivery size

Before installation of the heat recovery appliance is started, check that it has been supplied in complete and undamaged condition.

The delivery size of the heat recovery appliance type Ubiflux Vigor W325 consists of the following components:

1. Heat recovery appliance
2. Wall mounting bracket consisting of:
 - 1x mounting bracket
 - 2 x protective caps
 - 2x rubber strip
 - 2x rubber rings
3. Siphon
4. Documentation set consisting of:
 - 1x occupant's instructions



2 General

The Ubiflux Vigor W325 and the Ubiflux Vigor W325 Plus is a ventilation unit for the balanced ventilation of dwellings with heat recovery.

Features:

- Maximum capacity 325 m³/h
- High return plastic heat exchanger
- Filters ISO Coarse 60%
- Modular electric preheater
- Automatic bypass valve
- Touchscreen
- Adjustable air quantity
- Filter indication on the appliance and the possibility of a filter indication on the multiple switch
- An intelligent frost protection including modular preheater
- Low sound level
- Constant flow control

The Ubiflux Vigor W325 is available in two types:

- **the "Ubiflux Vigor W325"**
- **The "Ubiflux Vigor W325 Plus"**

The Ubiflux Vigor W325 Plus has, compared with standard Ubiflux Vigor W325, an extra pcb giving this more functions/ connection possibilities (>).

These installation instructions describe both the standard Ubiflux Vigor W325 and the Ubiflux Vigor W325 Plus.

The Ubiflux Vigor W325 and the Ubiflux Vigor W325 Plus are available in **Left-hand** and **Right-hand** versions; it is not possible to convert the left and right-hand models into one another.

For the correct connection ducts and dimensions (>).

It is possible, however, to later equip the appliance with a Plus pcb.

The appliance comes ready to plug in with a 230 V mains plug.


3 Version

3.1 Technical information

| Ubiflux Vigor W325 (Plus) | | | | | | | | | | |
|--|---|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| Supply voltage [V/Hz] | 230V/50Hz | | | | | | | | | |
| Dimensions (w x h x d) [mm] | 750 x 650 x 560 | | | | | | | | | |
| Duct diameter [mm] | ø160 | | | | | | | | | |
| External diameter condensate discharge [mm] | ø32 | | | | | | | | | |
| Weight [kg] | 37 | | | | | | | | | |
| Filter class | ISO Coarse 60% (ISO ePM1.0 50% for the air supply optional) | | | | | | | | | |
| Fan setting (factory setting) | 0 | 1 | | 2 | | 3 | | max | | |
| Factory setting [m³/h] | 50 | 100 | | 150 | | 250 | | 325 | | |
| Permissible resistance of duct system [Pa] | 2 | 6 | 9 | 24 | 21 | 53 | 59 | 148 | 100 | 250 |
| Rated power (excl. preheater) [W] | 6.1 | 6.6 | 7.9 | 10.3 | 15.1 | 21.0 | 46.6 | 69.1 | 87.5 | 144.5 |
| Rated current (excl. preheater) [A] | 0.08 | 0.08 | 0.09 | 0.11 | 0.15 | 0.21 | 0.41 | 0.59 | 0.73 | 1.07 |
| Max. rated current (incl. preheater switched on) [A] | 6 | | | | | | | | | |
| Cos φ | 0.341 | 0.343 | 0.389 | 0.394 | 0.430 | 0.439 | 0.492 | 0.507 | 0.521 | 0.542 |
| Sound power | | | | | | | | | | |
| Ventilation capacity [m³/h] | | 100 | 150 | 150 | 200 | 200 | 250 | 250 | 325 | |
| Sound power level Lw(A) | Static pressure [Pa] | 25 | 25 | 50 | 50 | 100 | 100 | 150 | 150 | |
| | Casing radiation [dB(A)] | 27 | 34 | 35 | 40 | 41 | 46 | 46 | 51 | |
| | Duct "From dwelling" [dB(A)] | 32 | 40 | 38 | 46 | 44 | 49 | 49 | 55 | |
| | Duct "To dwelling" [dB(A)] | 44 | 49 | 51 | 55 | 57 | 61 | 62 | 69 | |
| | Duct "From outside" [dB(A)] | - | - | - | - | - | - | - | 56 | |
| | Duct "To outside" [dB(A)] | - | - | - | - | - | - | - | 68 | |

*) Duct noise including end correction

In practice the value may differ by 1dB(A) through measurement tolerances.




Note:

The stated value in the circle is the capacity (in Watt) per fan.

3.2 Connections and dimensions

The Ubiflux Vigor W325 appliance is available in a left-hand and right-hand version. With a left-hand version the “warm” connections (from dwelling 3 and to dwelling 1) are on the left-hand side of the appliance; the condensate discharge is then mounted at the right-hand opening below the appliance. With a right-hand version the “warm” connections (1 & 3) are on the right-hand side of the appliance.


Left-hand version



All dimensions in millimeters. Diameter of all collars is 160 mm

| | | |
|----------|------------------------|--|
| 1 | To dwelling | |
| 2 | To outside | |
| 3 | From dwelling | |
| 4 | From outside | |
| 5 | Electrical connections | |
| 6 | Siphon connection | |
| 7 | Exhaust air filter | |
| 8 | Supply air filter | |
| 9 | Mounting | |


Right-hand version



All dimensions in millimeters. Diameter of all collars is 160 mm

| | | |
|----------|------------------------|--|
| 1 | To dwelling | |
| 2 | To outside | |
| 3 | From dwelling | |
| 4 | From outside | |
| 5 | Electrical connections | |
| 6 | Siphon connection | |
| 7 | Exhaust air filter | |
| 8 | Supply air filter | |
| 9 | Mounting | |

3.3 Exploded view of appliance



The appliance shown above is a left-hand version: in the case of a right-hand version, the connector of the preheater, bypass valve and the siphon connector are installed in mirror image!

| | | | |
|----|------------------------------|----|---------------------------------|
| 1 | Touchscreen | 12 | Heat exchanger |
| 2 | USB connector (X13) | 13 | Motor bypass valve |
| 3 | Service connector | 14 | Discharge filter |
| 4 | LED indicator | 15 | Bypass valve |
| 5 | Maximum protection preheater | 16 | Power cable 230 volt |
| 6 | Preheater | 17 | Relay output (X19)) |
| 7 | Temperature sensor | 18 | 24 volt connector (X18) |
| 8 | Supply filter | 19 | eBus connector (X17) |
| 9 | Exhaust fan | 20 | 24 volt connector (X16) |
| 10 | Siphon connector | 21 | Modbus/ bus connector (X15) |
| 11 | Supply ventilator | 22 | Multiple switch connector (X14) |

4 Operation

4.1 Description

The appliance is supplied ready for plugging in and works automatically according to the standard settings. The discharged dirty indoor air warms up the fresh clean outdoor air. That saves energy while fresh air is supplied to the desired rooms.

The control system has four ventilation modes. The air flow rate can be adjusted for each ventilation mode. The constant volume control system ensures that the ventilation balance between the supply and exhaust fan is realized independent of the duct pressure.

If no external control is connected on to the appliance, then the appropriate ventilation model can be chosen on the touchscreen display.

For external control a 4-way switch (→ [Connecting extra multiple switch with filter indication](#) page 38) can, for example, be chosen, but control is also possible with the Air Control (→ [Connecting Air Control](#) page 40), CO₂ sensor(s) (→ [Connecting CO₂ sensor\(s\)](#) page 42), a humidity sensor (→ [Connecting humidity sensor](#) page 41), 2-zone demand control (→ [Demand-driven ventilation 2.0](#) page 43) of the App.

4.2 Bypass

The 100% bypass makes it possible to supply outside air, which is not heated up by the heat exchanger.

Particularly during summer nights it is desirable to supply cooler outside air. The warm air in the dwelling is then replaced as much as possible by cooler outside air.

The bypass valve opens and closes automatically when a number of conditions are met (see table below for bypass conditions).

Follow step numbers 2.1 to 2.6 in the settings menu in the user interface, (→ [Setting values standard appliance](#) page 49) in order to adjust the operation of the bypass valve.

Bypass valve preconditions

| | |
|----------------------------|--|
| Bypass valve open | <ul style="list-style-type: none">▪ The outdoor temperature is higher than 10°C (adjustable between 7°C and 15°C at step no. 2.3) and▪ the outdoor temperature is lower than the indoor temperature of the dwelling and▪ the outdoor temperature is higher than 22°C (adjustable between 15°C and 35°C at step no. 2.2) |
| Bypass valve closed | <ul style="list-style-type: none">▪ The outdoor temperature is lower than 10°C (adjustable between 7°C and 15°C at step no. 2.3) or▪ the outdoor temperature is higher than the indoor temperature of the dwelling or▪ the temperature from the dwelling is lower than the set temperature at step no. 2.2 in the settings menu minus the set temperature at the hysteresis (step no. 2.4: the factory setting for this temperature is 20°C [22.0°C minus 2.0°C]). |

The appliance features a 'Bypass boost' function. This means that when this function is switched on (can be switched at step 2.5) the ventilation mode with an opened bypass valve goes to maximum air flow rate (adjustable at step no. 2.6).

4.3 Frost protection

To prevent freezing of the heat exchanger at low outdoor temperatures, the appliance features a frost control.

Temperature sensors measure the temperatures in the appliance, when required a preheater is switched on. If in the event of very low temperatures the preheater has insufficient capacity, stepless unbalance is created in the appliance.

The software 'recognizes' the appliance.


4.4 Plus version

The 'Plus' version is equipped with an extra control board with more connections for various applications.

This extra control board is located in a plastic housing behind the existing control board on top of the appliance.

It is also possible to remove the entire Plus pcb including casing from the appliance and mount it on, for example, a wall separate from the heat recovery appliance; this can be handy in certain circumstances such as a poor WiFi signal from the Plus pcb.

A standard heat recovery appliance can also later be modified into a Plus version using the Plus pcb upgrade set.



1 = Ubiflux Vigor W325 appliance with mounted Basic pcb

2 = Plus pcb mounting plate

3 = Plus pcb

4 = Plus pcb protective cap

5 Installation

5.1 Installation general

Installing the appliance:

1. Placing the appliance (→ [Placing the appliance](#) page 13)
2. Connecting the siphon and condensate discharge (→ [Connecting the condensate discharge](#) page 14)
3. Connecting the air ducts (→ [Connecting air ducts](#) page 15)
4. Electrical connections (→ [Electrical connections](#) page 16)

The installation and installing should meet the following requirements:

- Quality requirements of ventilation systems in homes, ISSO 61.
- Quality requirements of balanced ventilation dwellings, ISSO 62
- Regulations regarding the ventilation of homes and residential.
- Safety provisions for low-voltage installations
- The regulations for connecting indoor plumbing in homes and residential buildings.
- Any additional regulations of the local power companies
- The installation regulations of the Ubiflux Vigor W325 appliance.
- In addition to the above design and installation requirements and recommendations, the national building and ventilation regulations must be respected.

5.2 Placing the appliance

The Ubiflux Vigor W325 (Plus) appliance can be mounted onto the wall with the supplied mounting bracket. For a vibration-free installation, the appliance must be mounted to a solid wall with a minimum mass of 170 kg/m². A gypsum block or metal stud wall does not suffice! Additional measures such as double panelling or extra studs are required in that case. On request, a mounting support for floor mounting (with the same minimal mass) is available.

In addition, the following aspects must be taken into account:

- The appliance must be installed in an insulated frost-free room, in order to, for example, prevent freezing of the condensate discharge
- The appliance must be placed level.
- The appliance must not be placed in a room with a high level of condensation (such as a bathroom and/or laundry room).
- In order to prevent condensation on the outside of the appliance, the installation room must be ventilated.
- The installation room must be able to provide a condensate discharge with a sufficient water seal and drop for the condensed water.
- Newly built houses with a lot of moisture from the construction work need to be ventilated in a natural manner before being put to use.
- Make sure there is a free space of at least 70 cm at the front of the appliance and a free headroom of 1.8 m.
- Make sure there is a free space of at least 25 cm above the appliance, for connecting the appliance and any necessary servicing of the circuit board.

5.3 Connecting the condensate discharge

The condensate discharge line for the Ubiflux Vigor appliance is located in the lower panel. The condensate is discharged through the drainpipe. The siphon (with built-in aerator) is supplied separately with the appliance and must be fitted by the installer below the appliance (bayonet connection). The siphon has an external connection diameter of 32 mm. The siphon is connected to the inner sewer system. It is recommended to fit an odor trap between the sewer system and siphon in order to avoid unpleasant odors.




Important

Never switch the two condensate discharge connections below the appliance!

It is recommended to use a 32 mm connection with gasket (HT DN32) (not supplied with the appliance) so that the siphon can be cleaned easily in the future.

Important: During assembly always apply a lubricant, such as acid-free vaseline, to the rubber sealing ring in the gasket. This gasket connection has to be disconnected when servicing the appliance! The siphon must not be glued to the condensate discharge line.

The condensate discharge can be connected, for example, with a straight or angled connection with gasket. Slide the condensate discharge connection with gasket with sufficient length across the connection of the siphon.



- A = Ubiflux Vigor W325 right-hand version
- B = Fitting siphon below in Ubiflux Vigor appliance
- C = Examples with condensate discharge connections with gasket HT DN32
- D = Detachable connection
- E = Example of odor trap

5.4 Connecting air ducts

All air ducts must be installed airtight. The collars on the Ubiflux Vigor appliance are provided as standard with sealing rings.

In order to prevent condensation on the outside of the outdoor air supply duct and the air exhaust duct from the Ubiflux Vigor appliance, these ducts have to be provided with an external vapor barrier as far as the appliance. If thermally insulated piping is used here, additional insulation is not necessary.

For compliance with the maximum installation noise level of 30 dB(A), it will have to be assessed for every installation what measures will be required to limit the noise. In order to optimally dampen the noise of the fans from and to the dwelling through the duct, at least mufflers of no less than 1 m are required, but additional measures may be necessary.

Prevent crosstalk through the air supply and discharge ducts by using separate branches to the diffusers. If necessary, the supply ducts must be insulated, for instance when they are installed outside the insulated envelope.

The outside air supply should be arranged from the shadowed side of the dwelling, preferably from the wall or an overhang.

The discharge duct must be fed through the roof boarding in such a way that no condensation forms in the roof boarding.

The discharge duct between the Ubiflux Vigor appliance and the roof sleeve should be such that surface condensation is prevented.

Always use an insulated ventilation roof sleeve.

In order to keep the noise levels down, it is recommended to restrict the external duct pressure to 100 Pa. If the resistance of the duct system is higher than the maximum curve of the ventilator, the maximum ventilation capacity will be lower.


The air speeds must be limited to a max. of 5 m/s in the main ducts and 3.5 m/s in the branches.

The location of the discharge of the mechanical ventilation air and the sewer stack vent must be chosen to prevent noise nuisance.

The location of the input valves must be chosen in such a way to prevent fouling and drafts. We recommend using input valves.

When using flexible mufflers, account must be taken during the installation that these may need to be replaced after a period of time.

Install sufficient overflow openings, door gap 2 cm.




- 1 = Ubiflux Vigor W325 right-hand version (place level)
- 2 = Preferred ventilation air supply
- 3 = Sewer release
- 4 = Preferred location of ventilation air discharge; Use insulated ventilation roof sleeve
- 5 = Thermally insulated piping
- 6 = Condensate discharge
- 7 = Sound absorber(s)
- 8 = Duct to and from house
- 6 = Condensate discharge
- 7 = Sound absorber(s)
- 8 = Duct to and from house

5.5 Electrical connections

5.5.1 Connecting the power plug

The appliance can be connected to an easily accessible, earthed wall socket with the plug that is mounted to the appliance. The electric installation must comply with the requirements of your power company.



5.5.2 Connecting the multiple switch

The multiple switch (not supplied with the appliance) is connected to the modular connector type RJ12 (connector X14) that is placed on the rear of the display cap of the appliance (→).

For connection examples of multiple switch (→ [Connecting position switch](#) page 36). A wireless remote control (→ [Connecting wireless remote control \(without filter indication\)](#) page 37) and a combination of multiple switches is also possible (→ [Connecting extra multiple switch with filter indication](#) page 38).

The 4-way switch can also be used to activate a 30-minutes boost mode by putting the switch to setting 3 for less than 2 seconds and directly turning it back to setting 1 or 2. The boost mode can be reset by putting the switch to setting 3 for longer than 2 seconds or by switching it to absence mode (☞).

There is the option of demand-driven ventilation 2.0 (clock-driven or CO₂-driven) (→ [Demand-driven ventilation 2.0](#) page 43).

5.5.3 Connecting the eBus connector

For connecting an eBus connector, the 2-pole detachable (green) connector X17 is located at the rear of the display cap (→).

The eBus protocol may for instance be used to connect the Air Control (→ [Connecting Air Control](#) page 40).

Because of polarity sensitivity, always connect contacts correctly; the appliance will not work if these contacts have been interchanged!

The optional CO₂ sensor(s) or an extra eBus preheater or postheater (→ [Electrical diagram](#) page 34) can also be connected onto the eBus connector.

5.5.4 24 volt connection

On the X16 & X18 connector of the basic pcb, 24 volt is available.

Connector X-16 is for 24 volt connection of the optional Plus pcb.

For position connection (black) connector X16 & X18 (→ [Electrical diagram](#) page 34).

Maximum current reduction at plug X16 and X18 is 5 VA per connection.

5.5.5 Connecting humidity sensor

The optional humidity sensor has to be connected onto the the X07 connection of the basic pcb. For this, use the cable supplied with the humidity sensor. In order to connect the humidity sensor, the plastic cover above the control has to be taken off, after which the X07 connection is accessible.

For connecting the humidity sensor, see → [Connecting humidity sensor](#) page 41.

5.5.6 Bus Connection

The Modbus/ bus (red) connector X15 can for example be used for coupling appliances (→ [Coupling appliances using Bus](#) page 18).

The function of this connector can be adjusted using step number 14.1 to 14.4 in the settings menu.

If the appliance is fitted with a Plus pcb, then this red connector X15 is also in use for connecting the Plus pcb; several cables then have to be connected onto this connector X15.

5.5.7 Connecting "signal output" connector

The blue 2-pole screw connector X19. This connection is used to give a filter message or fault message.

If a filter or fault message is given in the appliance a contact is closed at connection X19. The operation of this is set by following step number 16.1.

5.5.8 ModBus Connection

The appliance can be connected with a ModBus system such as a building management system. Using the (red) 3-pole connector X15 (or with the Plus version the red connector X06 on the UWA2-E pcb) a connection can be made between the appliance and the ModBus system; (→ [Electrical diagram](#) page 34) for the right connection. For the correct setting of the jumpers X12, X121 & X122 see the explanation given with electrical diagram (→ [Electrical diagram](#) page 34); for more information and the correct modBus settings see the separate Modbus manual on the website!

Note: When ModBus is active, the ventilation mode cannot be changed using the display or, if applicable, the connected multiple switch! Also any connected humidity sensor will not function.

5.5.9 Coupling appliances using Bus




Important

Because of polarity sensitivity, always connect the Bus contacts X15-1 with one another, and the contacts X15-2 and the contacts X15-3 with one another. Never connect X15-1, X15-2 or X15-3 with one another!

Comment: If a Plus pcb has been installed; several cables would have to be connected onto the X-15 connector.

Note: When the total length of the Bus cables is longer than 10 m, then use a twisted-pair cable for connection X15-2 & X15-3 (a twisted pair cable is also preferred with shorter lengths)!



For M (master):

Step no. 8.1 - Master
Step no. 14.1 - Bus

For S1 (Slave 1):

Step no. 8.1 - Slave
Step no. 14.1 - Bus

For S2 (Slave 2):

Step no. 8.1 - Slave
Step no. 14.1 - Bus

A = Multiple switch

B = 3-pole connector red

C = Modular cable

D = 3-core low voltage cable

M = Master appliance (For example a Ubiflux Vigor appliance type 4-0)

S1 / S2 = Slave appliances (For example a Ubiflux Vigor appliance type 4-0); connect maximum of 10 appliances via Bus

All Ubiflux Vigor W325 appliances have the same air flow rate as the appliance that is set as "Master".

The fault messages of **all** appliances are shown on the display of the master appliance.


When using a Air Control or the Home, always connect this to the Master.

6 Display

6.1 General explanation of control panel

A display with touchscreen is located at the front of the appliance. This display is used to operate the appliance and to provide the user with information about the status of the appliance. When the mains power is switched on, the software version is first shown; the main screen is then displayed.

Main screen



1 = Current time

2 = Info connections (only displayed if applicable)

3 = Current date

4 = Set ventilation flow rate; the red bars indicate the selected ventilation flow rate.
In this example the active ventilation flow rate is 100 m³/h

5 = Active control

6 = Filter message (only displayed if applicable)*


7 = Fault (only displayed if applicable)*

8 = Access to settings menu

9 = Access to information menu

* Filter message and fault message are located in the same place on the display; fault display has a higher priority, and so will always be shown first even when there is an active filter message!


The factory setting of the menu is English.

The desired language/ date & time can be modified in the settings menu ; for this, please refer to the settings value table (→ [Setting values](#) page 49) step number 15.1 to step number 15.10.

6.2 Display layout

The screen is divided up into 6 zones where various symbols/displays can be shown per zone.















Layout of main screen






- 1 = Navigation screen
- 2 = Notification screen
- 3 = Screen with main function
- 4 = Connectivity information
- 5 = Time
- 6 = Date

The various symbols can be shown on the display. This depends on the screen that is shown, the version of the appliance and any connected accessories.

| Zone no. | Symbol on display | Description |
|----------|-------------------|---|
| 1 | | By pressing here you get access to the information menu; here one can only read out values. It is not possible to change these values. |
| | | By pressing here you get access to the settings menu. In this menu you can change the various values. For all setting values of standard appliance (→ Setting values standard appliance page 49). The Plus version of the appliance has various setting values (→ Setting values appliance with Plus pcb page 52). Caution: Incorrect settings can disrupt the operation of the appliance! |
| | | Use these arrows to go up or down the various menus or to increase or decrease the values of the relevant settings. |
| | | This arrow takes you back one step in the menu. |
| | | This takes you back to the main screen. |
| 2 | | Filter message symbol; this is only shown if the filter has to be cleaned or replaced. See chapter "Filter cleaning" (→ Cleaning filter page 29) for more information. |
| | | This symbol is only shown if a fault has occurred in the appliance; see chapter Faults (→ Fault analysis page 26) for more information. |



| Zone no. | Symbol on display | Description |
|----------|---|---|
| 3 |  | Control using multiple switch. |
| |  | Control by means of Home. |
| |  | Control using touchscreen on appliance; this setting is active for half an hour. |
| |  | Control using touchscreen on appliance; touchscreen is permanently set as multiple switch by setting step number 15.8 to "yes". |
| |  | Control using humidity sensor. |
| |  | Control using CO ₂ sensor. |
| |  | Control using demand-driven ventilation. |
| |  | Break contact active or make contact active. |
| |  | This appliance is set as Master appliance if a number of appliances are connected (cascade) |
| |   | Appliance is set as Slave appliance; maximum of 9 appliances can be connected to a Master. |
| |  | Control via eBus for example Air Control . |
| |  | Control via ModBus or Bus. |
| |  | Bypass boost is active. |

| Zone no. | Symbol on display | Description |
|----------|---|------------------------|
| 4 |  | Internet connection |
| |  | Signal strength |
| |  | USB connection active. |
| 5 | 11:07 | Current time. |
| 6 | 02.11.17 | Current date. |


6.3 Display information

When no keys are operated or when no deviating situation has developed (such as fault message or filter message) then the light will go out two minutes after the last key has been operated.


When there is a filter message or a fault in the appliance, then the light of the display will be on permanently until the fault has been solved or the filter message has been reset.

Pressing the Home button  brings you back to the main screen from any particular menu; pressing the return button  takes you back 1 step in the menu.

Briefly press the display (shorter than 5 seconds) to switch on the display backlight without changing anything in the menu; the display lights up for 2 minutes.



By pressing one of the quarter circles on the main screen, the ventilation mode can be quickly adjusted. The ventilation mode that has been set in this way remains active for half an hour; this is visible on the display by a hand with a clock.



The touchscreen can also be permanently set as multiple switch; to do this step number 15.6 in the settings menu has to be set to "yes".



Warning:

Incorrect settings can seriously disrupt the proper functioning of the appliance!


7 Starting appliance

7.1 Switching appliance on and off

Switching on:

▪ Switching on the mains power:


1. Connect the 230 V power plug to the electric system.
2. During the startup of the appliance, the version of the software is displayed. If the appliance has been without power for a long time (more than approx. 1 week), you will have to reset the correct language, time and date in setting menu ⚙️.
3. The appliance will then operate immediately after this according to the mode of the multiple switch. If no multiple switch is connected then the appliance operates always in mode 1.



Switching off:

▪ Switching off mains power:

1. Pull the 230 V power plug from the electric system; the appliance is now free of voltage.
2. Nothing is now shown on the display.



Warning!

When working on the appliance, always first take the voltage from the appliance by pulling the power plug.

7.2 Setting the air flow

Good ventilation contributes to healthy air in the home, optimal comfort and the proper functioning of the installation.

The air flows of the appliance have been set in the factory as follows 50, 100, 150 and 250 m³/h. The performance and the energy consumption of the appliance depend on the pressure drop in the duct system, as well as on the filter resistance. If these conditions are not complied with, the air flow rate of the higher mode will automatically be adjusted.

Changes can be carried out in the settings menu ⚙️.

Go in the settings menu to steps 1.2 to 1.4 to adjust the air flow.

Please note!


The highest demanded ventilation mode has priority. If the external multiple switch is set to mode 3, then the ventilation mode cannot be adjusted to a lower mode on the main screen.

An exception to this is ventilator mode 0. If mode 0 is chosen on the display: control from other switches, sensors, etc. is not possible.

For connected CO₂ sensors the air flow will be steplessly controlled between mode 1 and 3 depending on the measured PPM values: for a connected humidity sensor the air flow will be switched to mode 3 when this is switched on.

7.3 Other settings for installer

In addition to the air flow, it is also possible to change other settings of the appliance; for an overview of these settings of a standard appliance (→ [Setting values standard appliance](#) page 49) and appliance with Plus pcb (→ [Setting values appliance with Plus pcb](#) page 52).

Changes can be carried out in the settings menu .



Warning:

As changes in the settings menu can disrupt the proper functioning of the appliance, changes of settings not described here require consultation with Ubbink NV. Incorrect settings may seriously affect the proper performance of the appliance!

7.4 Factory settings

It is possible to simultaneously revert all the changed settings back to the factory settings.

All changed settings are then back to the values they had when they left the factory; all message and fault codes are also deleted from the service menu.

The filter message, however, is not reset!

For returning to factory settings, open the settings menu .

Under appliance settings, the appliance can be returned to factory settings through step number 15.9.

8 Fault

8.1 Fault analysis


When the appliance's control system detects a fault, this is indicated on the display by a spanner symbol, possibly also with a fault number.

The appliance makes a distinction between a fault at which the appliance keeps running (limitedly) and a serious (locking) fault for which both fans are switched off.


8.2 Display Codes

Non-locking fault

When the appliance detects a non-locking fault, it will keep running (limitedly). The (permanently lighted) display shows the fault symbol. Press the fault symbol for an explanation/ solution to the fault.



The screen can be left by pressing the "Home" button.
If a fault cannot be solved, please contact the installer.




1. Requested supply flow rate is not reached

Locking fault

When the appliance detects a locking fault, it will no longer work. With a locking fault the settings and information menu are also switched off.

The (permanently lighted) display shows the fault symbol (spanner) together with a fault code. The red LED on the multiple switch (if applicable) will be blinking. The appliance remains in this fault mode until the problem in question has been solved. Then the appliance will reset itself (Auto reset) and the display returns to the display of the operating situation. Contact the installer to remedy this fault.



1. Supply fan defective

A locking fault cannot be remedied by taking the voltage from the appliance; first the fault has to be solved.



Warning!

When working on the appliance, always first take the voltage from the appliance by pulling the power plug.

In the table below the locking faults are marked with an * after the fault number.

The display shows a brief explanation of this fault code.

If there is reference to the "Standby" mode of the appliance, then both fans are shut down but there is still something shown on the display of the appliance.


| Fault code | Sub code | Cause | Appliance action | User action |
|------------|----------|---|--|--|
| E190 | E1000 | Self-test not good | No action | |
| E152 * | E1001 * | Flash memory faulty | Stop appliance if possible | Replace basic pcb UWA2-B |
| E153 | E1002 | EEPROM memory defective | Appliance goes to factory setting; fan setting 2 | Replace basic pcb UWA2-B |
| E105 | E1011 | Requested supply flow rate is not achieved | None | Clean or replace filters Check that ducts are not blocked |
| E104 | E1012 | Requested exhaust flow rate is not achieved | None | Clean or replace filters Check that ducts are not blocked |
| E000 * | E1013 * | Temperature of outside air too high | Appliance goes to standby | Depending on the situation: In the event of warm weather and a supply directly below the tiles, wait until the air has cooled or install a roof sleeve instead of duct under the tiles In the event of cold weather or when there is no air from below the tiles, take the voltage from the appliance and replace air temperature sensor (NTC) |
| E105 * | E1100 * | Supply fan defective; general message | Appliance goes to standby | Replace supply fan Fault is reset automatically when voltage is put back on appliance. |
| E104 * | E1120 * | Exhaust fan defective; general fault message | Appliance goes to standby | Replace exhaust fan Fault is reset automatically when voltage is put back on appliance. |
| E103 | E1200 | Bypass defective; general fault message | None | Check wiring Replace bypass or wiring harness |
| E106 * | E1300 * | Sensor NTC1 defective; general fault | Appliance goes to standby | Check wiring Replace NTC sensor or replace wiring |
| E111 | E1400 | RHT sensor 1 defective; general message | No humidity control | Check wiring Replace RHT sensor or replace wiring |
| E113 | E1600 | Internal preheater defective; general fault message | Frost protection goes to imbalance mode | Check fuses Check wiring; replace if damaged and replace otherwise the internal preheater Fault is automatically reset when the voltage is put back on the appliance. |
| E114 | E1500 | Multiple switch defective; general fault | Appliance goes to mode 1 | Replace multiple switch |
| E130 | E1800 | Relay output 1 defective; general fault | Signal output not available | Take voltage from appliance Replace UWA2-B pcb Fault is automatically reset when voltage is again put back on appliance. |

| Fault code | Sub code | Cause | Appliance action | User action |
|-------------------|-----------------|---|---|--|
| E155 | E2000 | Touchscreen fault; general fault message | Fault codes only visible when using service tool | Check wiring to touchscreen; replace wiring if damaged; replace touchscreen if fault still occurs replace UWA2-B Fault is automatically reset when voltage is again put back on appliance |
| E120 | E2100 | EBus fault; general fault message | Air Control and other accessories connected to eBus do not work. Appliance is working | Check wiring to accessories/ Air Control Check accessories/ Air Control and replace if defective If there is still a fault after this: Take voltage from appliance and replace basic pcb UWA2-B |
| E121 | E2200 | Bus general fault message | Air Control and other accessories do not work. Appliance is working | Check wiring to accessories/ Air Control Check accessories/ Air Control and replace if defective If there is still a fault after this: Take voltage from appliance and replace basic pcb UWA2-B |
| E122 | E2300 | Internal ModBus fault; general fault message | Appliance goes to standby | Check wiring and connections to UWA2-B and the fans Replace cable harness if damaged; Then exchange UWA2B, exhaust fan and supply fan |
| E123 | E2400 | External ModBus fault; general fault message | Operation via Modbus does not work | Check cabling of accessories; replace if damaged Check accessories; replace if defective If fault still occurs: Take voltage from appliance and replace UWA2-B basic pcb |
| E124 | E2500 | USB port general fault message | USB interface not usable | Replace USB accessory If the fault is not remedied after this: take the voltage from the appliance and replace UWA2-B basic pcb |
| E170 | E2600 | One or more CO ₂ sensor(en) defective; general fault message | Appliance is working; no CO ₂ regulation | Check cabling and CO ₂ sensor(s); replace if damaged Check CO ₂ sensor(s); replace if defective |
| E171 | E2700 | External preheater or fuse defective; general fault message | No preheater / comfort control responds differently | Uncouple preheater and check preheater fuse; replace fuse if defective Has the fault not yet been remedied: Replace external preheater Put voltage back on appliance Fault has automatically been reset |
| E172 | E2800 | External postheater or fuse defective; general fault message | No postheater / comfort control responds differently | Uncouple postheater and check postheater fuse; replace fuse if defective Has the fault not yet been remedied: Replace external postheater Put voltage back on appliance Fault has automatically been reset |

9 Maintenance

9.1 Cleaning filter

The maintenance for the user is limited to the periodic cleaning or replacement of the filters.


The filter only has to be cleaned if this is indicated on the display (the filter symbol is shown here)  or, if a multiple switch with filter indication has been installed and the red LED of the switch is on.

The filters should be replaced each year.

After the filter has been cleaned 3 times, it must be replaced by the 4th time.


The appliance must never be used without filters.

Cleaning and replacing the filters:


Press the filter symbol  for longer than 3 seconds to open the filter wizard.

Now follow the instructions that appear on the display to clean and/or replace the filter.



This filter wizard cannot be interrupted.

When all the instructions on the menu have been followed and confirmed, then the filter wizard is closed by pressing  the "Home" button and the display then returns to the main screen; the filter message is reset and the filter message now disappears.



Comment:

If the filter wizard is opened in order to replace the filter whilst there is no filter message on the display screen, go in the settings menu  to step number 4.2 to open the filter wizard. Now follow the instructions on the display, and once finished the timer of the filter message is reset.

It is also possible to go in the settings menu using step number 4.3 to reset the filter directly without opening the filter wizard; if "Yes" is chosen then in the settings menu this step number has to be left again by pressing

"Home" button  or the "return" button .


The timer of the filter message is then reset!

Pressing the Home button  brings you back to the main screen from any particular menu; pressing the return button  takes you back 1 step in the menu.


9.2 Maintenance

Installer maintenance includes cleaning the heat exchanger and fans. Dependent on the conditions, this must be done about once every three years.


- 1 Remove the power supply by pulling out the plug.
Open the filter door.




- 2 Remove the two filters.




- 3 Remove the front cover.




- 4 Remove the heat exchanger. Be careful not to damage the foam parts in the appliance.




- 5 Wash the heat exchanger with hot water (max. 45°C) and a regular detergent. Then rinse the exchanger with hot water.




- 6 Take EPS assembly, with which the fan is inserted into the appliance, out of the appliance.




- 7 Turn the fan a quarter of a revolution in the appliance.



- 8 Tilt the fan in such a way that this can be taken out of the EPS assembly; disconnect both fan cables from the fan.




- 9 Now take the fan out of the appliance.



- 10 Repeat steps 6 to 9 for the other fan in the appliance.
- 11 Carefully clean both fans with a soft brush; do not use any water or cleaning agent.
- 12 Place both fans back in the appliance and connect the disconnected fan cables once more; when doing so, take care that the fan cables are "behind" the fans and that the fans are returned to their original position. The left fan is indicated by "Left"; the right fans is indicted by "Right".
Comment: Do not change the position of the fans!!!
- 13 Slide the cleaned heat exchanger carefully back into the appliance; when doing so, take care that the EPS parts and rails in the appliance are not damaged, which could otherwise leads to internal leaks in the appliance. Take care when returning the heat exchanger that the text on the type plate is not upside down!
Place the heat exchanger back such that this type plate is visible.
- 14 Put the front cover back on and screw it secure.
- 15 Install two new filters and close the front cover.
- 16 Reconnect the 230V power supply to the appliance.
- 17 Reset the timer of the filter message by setting the timer back to zero in the settings menu at step number 4.3.
- 18 After resetting the timer of the filter message the appliance returns to the main menu and the appliance is once again ready for use.

10 Electrical diagram



- 1 = Basic pcb UWA2-B
- 2 = Multiple switch (option)
- 3 = Humidity sensor (option)
- 4 = USB connector
- 5 = USB stick for updating software (not supplied with appliance)
- 6 = Service connector
- 7 = Laptop with installed service tool (not supplied)
- 8 = Touchscreen on appliance
- 9 = Valve motor bypass valve
- 10 = Air temperature sensor
- 11 = Exhaust fan*
- 12 = Internal preheater incl. maximum security
- 13 = Supply fan*
- 14 = Power supply 230V 50Hz
- 15 = Air Control (option)
- 16 = CO₂ sensor eBus (option)
- 17 = Heater eBus (option)
- 18 = Zone valve demand-driven ventilation 2.0 (option)
- 19 = Plus pcb UWA2-E (option)
- 20 = Connection on ModBus system (option)
- 21 = X12 is Jumper terminating resistance (120 Ω) ModBus (remove if terminating resistance has already been placed in ModBus system). With Modbus application remove the jumpers X121 & X122; when using Bus place the jumpers X12, X121 & X122; remove Jumper X07 from Plus pcb UWA2-E when a Plus pcb is applied.

* The control cables of the fans can be switched with no problem; when the power is switched on the appliance determines itself which is the supply and exhaust fan!
When the appliance detects another fan (for example when a fan is replaced during service activities), then a "wizard" starts up automatically; follow the instructions on the display for the correct connection of the fan cables.

Basic pcb UWA2-B

- X15 = Bus/ModBus
- X16 = 24V
- x17 = eBus
- X18 = 24V (max 5VA)
- X19 = Signal output

Plus pcb UWA2-E

- X03 = 24V
- X04 = Bus
- X06 = ModBus
- X08 = Contact input 1
- X09 = Contact input 2
- X10 = Relais output 1
- X11 = Relais output 2
- X12 = Analooog input (0 to 10 V)
- X13 = Analooog input (0 to 10 V)
- X14 = Analooog output (0 or 10 V)
- X15 = Analooog output 2 (0 or 10 V)
- X16 = NTC 10K
- X17 = LAN


Wire colours

- C1 = brown
- C2 = blue
- C3 = green/yellow
- C5 = white
- C8 = grey
- C10 = yellow
- C11 = green
- C17 = purple


11 Electrical connections accessories

11.1 Connecting position switch

A multiple switch must be connected to the modular connector type X14. This modular connector X14 is accessible from the rear of the control. With an appliance with Plus pcb the cover first has to be removed in order to gain access to this modular connector (→). Depending on the type of multiple switch that is connected, one can use either an RJ11 or RJ12 plug.




It is best to use a 4-way switch with filter indication; always install an RJ12 connector in combination with a 6-core modular cable.




When using a 3-way switch without filter indication always install an RJ11 connector in combination with a 4-core modular cable.

11.1.1 Connecting position switch with filter indication




- A = Ubiflux Vigor appliance (For example a Ubiflux Vigor appliance type 4-0)
- B = 4-way switch with filter indication
- C = Modular cable: Note: For the modular cable that is used, the “tab” of both modular connectors must be mounted facing the mark on the modular cable. Wire colors C1 - C6 may vary dependent on the type of modular cable used.

11.1.2 Connecting wireless remote control (without filter indication)




- A = Ubiflux Vigor appliance (For example aUbiflux Vigor appliance type 4-0)
- B = Receiver for wireless remote control
- C = Transmitter with 4 settings (for example kitchen)
- D = Transmitter with 2 settings (for example bathroom)
- E = Any additional 2- or 4-settings transmitters (maximum of 6 transmitters can be signed on to 1 receiver)
- F = Modular cable: Note: For the modular cable that is used, the "tab" of both modular connectors must be mounted facing the mark on the modular cable. Wire colors C1 - C6 may vary dependent on the type of modular cable used.

11.1.3 Connecting extra multiple switch with filter indication




- A = Ubiflux Vigor appliance(For example a Ubiflux Vigor appliance type 4-0)
- B1 = Multiple switch with filter indication
- B2 = Extra multi switch with filter indication
- C = Splitter
- D = Modular cable: Note: For the modular cable that is used, the “tab” of both modular connectors must be mounted facing the mark on the modular cable. Wire colors C1 - C6 may vary dependent on the type of modular cable used.

11.1.4 Connecting extra multiple switch with filter indication



- A = Ubiflux Vigor appliance (For example a Ubiflux Vigor appliance type 4-0)
- B = Multiple switch with filter indication
- C = Receiver for wireless remote control
- D = Transmitter with 2 settings or 4 settings
- E = Splitter
- F = Modular cable: Note: For the modular cable that is used, the “tab” of both modular connectors must be mounted facing the mark on the modular cable. Wire colors C1 - C6 may vary dependent on the type of modular cable used.

11.2 Connecting Air Control



A = Ubiflux Vigor W325 appliance


B = Air Control (option)

C = Two-core control cables

D = Green two-pole screw connector

E = Position green eBus connector to rear of control

11.3 Connecting humidity sensor



1 = Ubiflux Vigor W325 appliance

2 = Basis pcb

3 = Cover


4 = The cable that comes with RH cable

5 = RH (humidity) sensor

6 = Duct from dwelling

To switch on and set the sensitivity of the humidity sensor, go to step number 7.1 and 7.2 in the settings menu ⚙️.

11.4 Connecting CO₂ sensor(s)




A = Ubiflux Vigor W325 appliance

B = 2-pole control cable for 24V power supply (black connectors)

C = 2-core control cable for eBus connection (green connectors)

D = CO₂ sensor(s); connect a maximum of 4


E = Connection X17 (eBus) and X18 (24V) on Ubiflux Vigor appliance

For switching the CO₂ sensor(s) on and off, select the right setting at step number 6.1 in the settings menu ; in order to set the minimum and maximum PPM value of the CO₂ sensor(s) set, if necessary, the right values following step numbers 6.2 to 6.9.

11.5 Demand-driven ventilation 2.0

Demand-driven ventilation allows the ventilation need to be matched to the air quality. Matching the ventilation need with demand-driven ventilation can be done in two different ways, namely based on CO₂ measurements or based on a time program. Two different sets are available for this. Manual operation with the aid of an extra connected multiple switch of course remains a possibility as well.


For further information regarding setting, operating and connecting demand-driven ventilation 2.0, refer to the installation instructions supplied with the demand-driven device.



- 1 = Zone valve demand-driven ventilation
- 2 = Power 24 VDC
- 3 = Air Control
- 4 = Valve motor zone valve
- 5 = EBus connection X17 on Ubiflux Vigor appliance
- 6 = CO₂-sensors (only applicable when demand-driven based on CO₂)
- 7 = Pcb demand-driven
- 8 = Dipswitch setting on pcb zone valve

C1 = brown
 C2 = blue
 C3 = green/yellow
 C5 = white
 C10 = yellow
 C11 = green


11.6 Connecting postheater



- 1 = Heating coil
- 2 = Maximum safety with manual reset
- 3 = 2-pole eBus connection X17 on appliance
- 4 = Temperatur sensor
- 5 = PCB type UVP1
- 6 = Airflow direction
- 7 = Dipswitch setting postheater

- C1 = brown
- C2 = blue
- C3 = green/yellow
- C4 = black
- C5 = white

11.7 Connecting preheater



- 1 = Heating coil
- 2 = Maximum safety with manual reset
- 3 = 2-pole eBus connection X17 on appliance
- 4 = Temperature sensor
- 5 = PCB type UVP1
- 6 = Airflow direction
- 7 = Dipswitch setting preheater

- C1 = brown
- C2 = blue
- C3 = green/yellow
- C4 = black
- C5 = white

12 Service


12.1 Exploded view

When ordering parts, in addition to the article code number (see exploded view), please state the heat recovery appliance type, the serial number, the year of production and the name of the part:

N.B.: Appliance type, serial number and year of production are stated on the identification plate behind the plastic front panel on the appliance.

| Example | |
|--------------------|-------------------------|
| Appliance type | Ubiflux Vigor W325 Plus |
| Serial number | 430030191201 |
| Year of production | 2020 |
| Part | Fan |
| Article code | 0883255 |
| Quantity | 1 |

12.2 Service articles



| No. | Article description | Article code |
|-----|---|--------------|
| 1 | Front panel complete | 0883270 |
| 2 | Filters (2 items) ISO Coarse 60% | 0883266 |
| 3 | Heat exchanger | 0883260 |
| 4 | Fan (1 item) | 0883255 |
| 5 | Bypass valve with motor complete | 0883262 |
| 6 | Display pcb UBP-2 | 0883258 |
| 7 | Basic pcb UWA2-B | 0883244 |
| 8 | Plus pcb UWA2-E (only applicable with Plus version) | 0883246 |
| 9 | Mains plug and cable 230 V * | 0883261 |
| 10 | Internal preheater incl. maximum security | 0883263 |
| 11 | Temperature sensor NTC 10K | 0704637 |
| 12 | Condensation discharge | 0883264 |
| 13 | Cable set | 0883265 |

* The power cable is fitted with a circuit board connector. When replacing it, always order a replacement mains cable from Ubbink NV.

To prevent dangerous situations, a damaged mains connection can only be replaced by a qualified expert.

13 Setting values

13.1 Setting values standard appliance

The below setting values are for a Ubiflux Vigor W325-appliance **without** Plus pcb.

| Step No | Description | Factory settings | Setting range | Comment |
|----------|------------------------------------|------------------|---|--|
| 1 | Flow rate | | | |
| 1.1 | Air flow rate setting 0 | 50 m³/h | 0 or adjustable between 50 m³/h and 325 m³/h (never higher than step no. 1.2) | |
| 1.2 | Air flow rate setting 1 | 100 m³/h | Adjustable between 50 m³/h and 325 m³/h (not higher than step no. 1.3 or lower than step no. 1.1) | |
| 1.3 | Air flow rate setting 2 | 150 m³/h | Adjustable between 50 m³/h and 325 m³/h (not higher than step no. 1.4 or lower than step no. 1.2) | |
| 1.4 | Air flow rate setting 3 | 250 m³/h | Adjustable between 50 m³/h and 325 m³/h (not lower than step no. 1.3) | |
| 1.5 | Imbalance permissible | Yes | Yes / No | |
| 1.6 | Imbalance (Open fireplace) | 0% | 0% / +20% | |
| 1.7 | Offset supply | 0% | -15% / +15% fan setting | Value calculated back to set flow rate, see screen |
| 1.8 | Offset exhaust | 0% | -15% / +15% fan setting | |
| 1:19 | Default fan setting | 1 | 0 or 1 | |
| 2 | Bypass | | | |
| 2.1 | Mode Bypass | Automatic | - Automatic - Bypass closed - Bypass open | |
| 2.2 | Bypass temperature "from dwelling" | 22 °C | 15 °C / 35 °C | |
| 2.3 | Bypass temperature "from outside" | 10 °C | 7 °C / 15 °C | |
| 2.4 | Bypass hysteresis | 2 °C | 0 °C / 5 °C | |
| 2.5 | Mode Bypass boost | Off | On / Off | |
| 2.6 | Fan setting selection Bypass boost | 3 | 0 / 3 | |
| 3 | Frost protection | | | |
| 3.1 | Frost temperature | 0 °C | 0 °C / 3 °C | |
| 3.2 | Minimum intake temperature | 10 °C | 7 °C / 22 °C | |
| 4 | Filter message | | | |

| Step No | Description | Factory settings | Setting range | Comment |
|---------|--|------------------|--|------------|
| 4.1 | Number of days until filter message | 90 | 1 / 365 days | |
| 4.2 | Start of filter wizard | No | Yes / No | |
| 4.3 | Filter reset | No | Yes / No | |
| 5 | External heater | | | |
| 5.1 | Preheater on and off | Off | On / Off | |
| 5.2 | Postheater on and off | Off | On / Off | |
| 5.3 | Temperature postheater | 21 °C | 15 °C / 30 °C | |
| 6 | CO ₂ sensor | | | |
| 6.1 | Switching eBus CO ₂ sensor off and on | Off | On / Off | |
| 6.2 | Min. PPM eBus CO ₂ sensor 1 | 400 PPM | 400 - 2000 PPM | |
| 6.3 | Max. PPM eBus CO ₂ sensor 1 | 1200 PPM | | |
| 6.4 | Min. PPM eBus CO ₂ sensor 2 | 400 PPM | | |
| 6.5 | Max. PPM eBus CO ₂ sensor 2 | 1200 PPM | | |
| 6.6 | Min. PPM eBus CO ₂ sensor 3 | 400 PPM | | |
| 6.7 | Max. PPM eBus CO ₂ sensor 3 | 1200 PPM | | |
| 6.8 | Min. PPM eBus CO ₂ sensor 4 | 400 PPM | | |
| 6.9 | Max. PPM eBus CO ₂ sensor 4 | 1200 PPM | | |
| 7 | Humidity sensor | | | |
| 7.1 | Switching humidity sensor on and off | Off | On / Off | |
| 7.2 | Sensitivity of humidity sensor | 0 | +2 = most sensitive 0 = basic setting -2 = least sensitive | |
| 8 | Cascade | | | |
| 8.1 | Appliance setting | 0 (Master) | 0 / 9 (0=Master; 1 t/m 9 = Slave 1 t/m Slave 9) | |
| 12 | Central heating + heat recovery | | | |
| 12.1 | Status | Off | On / Off | |
| 14 | Communication | | | |
| 14.1 | Type of Bus connection | ModBus | Off / Bus/ ModBus | |
| 14.2 | Slave address | 20 | 1 - 247 | For Modbus |

| Step No | Description | Factory settings | Setting range | Comment |
|-----------|---------------------------|------------------|---|---|
| 14.3 | Baudrate | 19k2 | 1200 / 2400 / 4800 / 9600 / 19k2 / 38k4 / 56k / 115k2 | For Modbus |
| 14.4 | Parity | Even | No / Even / Odd | For Modbus |
| 15 | Appliance settings | | | |
| 15.1 | Language | English | English/ German/ French/ Dutch/ Lithuanian/ Danish/ Italian/ Polish/ Spanish/ Romanian/ Slovak/ Slovenian/ Estonian/ Norwegian/ Czech/ Hungarian/ Latvian | |
| 15.2 | Date format | dd-mm-yyyy | dd-mm-yyyy / mm-dd-yyyy | |
| 15.3 | Date | | | |
| 15.4 | Time format | 24h | 12h / 24h | |
| 15.5 | Time | | | |
| 15.8 | Display | No | Yes / No | Display half an hour active as multiple switch; when "yes" is selected touchscreen permanently set as multiple switch |
| 15.9 | Back to factory settings | No | Yes / No | |
| 15.10 | Fan position wizard | No | Yes / No | |
| 16 | Signal output | | | |
| 16.1 | Signal output | Off | Off / Only filter condition / Only fault condition / Filter and fault condition | Connector X19 |
| 17 | Standby | | | |
| 17.1 | Switch off appliance | No | Yes / No | |

13.2 Setting values appliance with Plus pcb

The below setting values are for a Ubiflux Vigor W325-appliance **with** Plus pcb.

| Step No | Description | Factory settings | Setting range | Comment |
|----------|---------------------------------|------------------|--|---------|
| 9 | Switch contacts | | | |
| 9.1 | Make or break contact 1 | Make | Make / Break | |
| 9.2 | Switch contact control 1 | Off | Off On Meets Bypass conditions Open bypass valve Open external valve | |
| 9.3 | Contact 1 Supply fan action | Fan off | Fan off Fan runs at absolute minimum Fan at setting 1 Fan at setting 2 Fan at setting 3 Fan at step 0 Fan according to multiple switch Fan runs at absolute maximum No supply fan control | |
| 9.4 | Contact 1 Exhaust fan action | Fan off | Fan off Fan runs at absolute minimum Fan at setting 1 Fan at setting 2 Fan at setting 3 Fan at step 0 Fan according to multiple switch Fan runs at absolute maximum No exhaust fan control | |
| 9.5 | Make or break contact 2 | Make | Make / Break | |
| 9.6 | Switch contact control 2 | Off | Off On Meets Bypass conditions Open bypass valve Open external valve | |
| 9.7 | Contact 2 Supply fan action | Fan off | Fan off Fan runs at absolute minimum Fan at setting 1 Fan at setting 2 Fan at setting 3 Fan at step 0 Fan according to multiple switch Fan runs at absolute maximum No supply fan control | |
| 9.8 | Contact 2 Exhaust fan action | Fan off | Fan off Fan runs at absolute minimum Fan at setting 1 Fan at setting 2 Fan at setting 3 Fan at step 0 Fan according to multiple switch Fan runs at absolute maximum No exhaust fan control | |

| Step No | Description | Factory settings | Setting range | Comment |
|---------|----------------------------|------------------|---|----------------|
| 10 | 0 - 10 V. | | | |
| 10.1 | Mode input 1 | Off | On / Off | Connector X-12 |
| 10.2 | minimum voltage input 1 | 0V | 0V / 10V | |
| 10.3 | maximum voltage input 1 | 10V | 0V / 10V | |
| 10.4 | Mode input 2 | Off | On / Off | Connector X-13 |
| 10.5 | minimum voltage input 2 | 0V | 0V / 10V | |
| 10.6 | maximum voltage input 2 | 10V | 0V / 10V | |
| 11 | Geo-heat exchanger | | | |
| 11.1 | Switching on and off | Off | On / Off | |
| 11.2 | Switch temperature 1 | 5 °C | 0.0 °C / 10.0 °C | |
| 11.3 | Switch temperature 2 | 25 °C | 15.0°C / 40.0 °C | |
| 11.4 | Mode valve 24 volt control | Closed | Open / Closed | |
| 11.5 | Valve control | Relay output 1 | Relay output 1/ Relay output 2/ Analogue output 1/ Analogue output 2 | |

14 Conformity declaration

Conformity declaration

Manufacturer: Ubbink NV

Address: Jan Samijnstraat 9
BE-9050, Gentbrugge, Belgium

Product: Heat recovery appliance type:
Ubiflux Vigor W325
Ubiflux Vigor W325 Plus

The product described above complies with the following directives:

- ◆ 2014/35/EU (low voltage directive)
- ◆ 2014/30/EU (EMC directive)
- ◆ RoHS 2011/65/EU (substances directive)
- ◆ 2009/125/EG (1253/1254 EU (EU ErP directive))

The product bears the CE label:



Gentbrugge, 01-06-2018

A handwritten signature in blue ink, appearing to be 'B. Vanlede', written over a faint circular stamp or background.

B. Vanlede
General Director

15 ERP values

| Technical information sheet Ubiflux Vigor W325 (Plus) in accordance with Ecodesign (ErP), no. 1254/2014 (Annex IV) | | | | | |
|--|---|--|-----------|---|-----------------------------------|
| Manufacturer: | | Ubbink NV | | | |
| Model: | | Ubiflux Vigor W325 (Plus) | | | |
| Climate zone | Type of control | SEC Value in kWh/m ² /a | SEC Class | Annual electricity consumption (AEC) in kWh | Annual heating saved (AHS) in kWh |
| Average | manual | -40.99 | A | 233 | 4614 |
| | clock control | -41.59 | A | 215 | 4628 |
| | 1x sensor (RV/CO ₂ /VOC) | -42.72 | A+ | 181 | 4657 |
| | 2 or more sensors (RV/CO ₂ /VOC) | -44.71 | A+ | 124 | 4714 |
| Cold | manual | -79.74 | A+ | 770 | 9026 |
| | clock control | -80.48 | A+ | 752 | 9054 |
| | 1x sensor (RV/CO ₂ /VOC) | -81.88 | A+ | 718 | 9110 |
| | 2 or more sensors (RV/CO ₂ /VOC) | -84.42 | A+ | 661 | 9222 |
| Hot | manual | -16.17 | E | 188 | 2086 |
| | clock control | -16.69 | E | 170 | 2093 |
| | 1x sensor (RV/CO ₂ /VOC) | -17.66 | E | 136 | 2106 |
| | 2 or more sensors (RV/CO ₂ /VOC) | -19.33 | E | 79 | 2132 |
| Type of ventilation unit: | | Balanced residential ventilation appliance with heat recovery | | | |
| Fan: | | EC - fan with infinitely variable control | | | |
| Type of heat exchanger: | | Recuperative plastic cross-counterflow heat exchanger | | | |
| Thermal efficiency | | 91% | | | |
| Maximum flow rate: | | 325m ³ /h | | | |
| Maximum rated power: | | 145 W | | | |
| Sound power level Lwa: | | 41 dB(A) | | | |
| Reference flow rate: | | 228m ³ /h | | | |
| Reference pressure: | | 50 Pa | | | |
| Specific Power Input (SEL): | | 0.15 Wh/m ³ | | | |
| Control factor: | | 1.0 in combination with multiple switch | | | |
| | | 0.95 in combination with clock control | | | |
| | | 0.85 in combination with 1 sensor | | | |
| | | 0.65 in combination with 2 or more sensors | | | |
| Leakage* | Internal | 2.85% | | | |
| | External | 2.85% | | | |
| Position dirty filter indication: | | On the display of the appliance / on the multiple switch (LED) / on the Air Control. Attention! For optimal energy efficiency and a proper operation, a regular filter inspection, cleaning or replacement is necessary. | | | |
| Internet address for Assembly instructions: | | http://www.ubbink.be | | | |
| Bypass: | | Yes, 100% Bypass | | | |

* Measurements executed by TZWL according to the EN 13141-7 standard

| Classification from 1 January 2016 | |
|-------------------------------------|-----------------------------|
| SEC class ("Average climate zone") | SEC in kWh/m²/a |
| A+ (Most efficient) | SEC < -42 |
| A | $-42 \leq \text{SEC} < -34$ |
| B | $-34 \leq \text{SEC} < -26$ |
| C | $-26 \leq \text{SEC} < -23$ |
| D | $-23 \leq \text{SEC} < -20$ |
| G (Least efficient) | $-20 \leq \text{SEC} < -10$ |

16 Recycling

Recycling

Sustainable materials are used in the manufacture of this appliance. The packaging should be disposed of in a responsible manner and in accordance with governmental regulations.





Ubbink BV
Jan Samijnstraat 9 - B - 9050 Gentbrugge
T +32 (0) 923 711 00

E-mail: info@ubbink.be
www.ubbink.be

Ubbink (UK) Ltd.
Unit 2, Redbourne Park, Liliput Road
Brackmills Ind. Est., Northampton, NN4 7DT
T +44 (0)1604 433000, F. +44 (0)1604 433001